

QBI-S

User Manual

v1.0





Thank you

Thank you for purchasing QBI-S module.

The idea behind QBI-S is to fulfill two fundamental functions when patching:

- Duplicate a signal*
- Invert a signal*

These are two basic yet important and essential functions when patching.

But even though they are important, we wanted them to take up as little space as possible.

We therefore imagined QBI-S is capable of:

- Invert 4 different signals with very high precision.*
- Duplicate a signal on 3 outputs without losses.*
- Duplicate and invert a signal on 4 outputs without losses.*

And the best of all is that you can add these different functions together to always meet your needs when patching.

Summary

01 Introduction

02 Installation & power safety

03 Overview

Follow Us

Instagram

modulargrid

Forum





1

Unplug you rack power from the main.

2

As shown on the sketch on the right, align the red line from the power ribbon cable with the line draw next to the power connector.

3

Check twice the alignment of the ribbon cable.

4

Plug you rack power to the main and power you rack.

General Specifications

⚡ Power Consumption

+12V : 10mA
-12V : 10mA
+5V : 0mA

↔ Panel Width

12 HP

↑↓ Module Depth

20mm - skiff friendly

Warranty

BLACK NOISE warrants its products to be free of defects in materials or workmanship and to conform with the specifications at the time of shipment for a period of two years from the date of purchase.

During that period any malfunctioning or damaged units will be repaired, service and calibrated into your workshop. This warranty does not cover any problems resulting from damages during shipping, incorrect installation or power supply, abusive treatment, or any other obvious user-inflicted fault.

If your product warranty is passed, it still can be serviced as long as parts are available in our workshop. We reserve the right to charge for labor, parts and transit expenses where applicable.

Before sending your product to our workshop please contact us for RMA and details. Any unsolicited parcel will be rejected and or returned. The postage to our workshop is on the customer. The return of your module is on us. BLACK NOISE can not take any responsibility for damages caused during transport.





